


User's instruction for all-purpose air conditioner remote controller

Product Introduction

Model K-1028E All-purpose Air Conditioner Remote Controller has been designed to remotely control various brands and models of the air conditioners. This product is characteristic of point-to-point fast brand searching and automatic digital code searching with low power consumption, complete functions, long transmission distance, easy setting, simple operation and fresh visual appearance and comfortable hand feel which can facilitate you with unlimited convenience. The product has a large LCD screen which provides easy setting and operation. It has built-in clock, on/off timer and night illumination function which have facilitated more convenience for you.

Panel Description:




Remarks:

Fast Cool/Heat Key

- Press "Fast Cool" key to automatically set the machine as refrigerating mode, 21°C, middle wind, automatic blowing direction;
- Press "Fast Heat" key to automatically set the machine as heating mode, 27°C, middle wind, automatic blowing direction.

Battery Installation:

1. Remove the battery cover of the remote control, install two new 7# batteries;



2. Install the battery cover. The time will appear in the left corner of LCD display.

Setting of Remote Control

This remote controller has four setting modes that are marked as A, B, C and D. Please select one mode for operation.

A The brand corresponding point-to-point fast searching

1. Manually plug-in the air conditioner, aim the remote control at the receiving window of the air conditioner.



2. Press the code key that corresponds to your brand and hold until the air conditioner is started by giving out a sound signal. Release the key and the setting is completed.



Table of brand corresponding keys

GREE/Haier	MDTOSHIBA/CHANGHONG	SHARP/KELONG	MITSUBISHI/OTHER	LG/SAMSUNG
SANYO/HISENSE	CHIGO/DAIKIN	FUJITSU/CARRIER	CHUNLAN/AUX	SHINCO/AUCMA

B Manually input code


1. Manually plug-in the air conditioner, find the type of the air conditioner in the "Code Table", and find the first code, for example: Haier

BRAND	CODE
HAIER	001-019

2. Hold SET button (for about three seconds) until the conditioner type code flickers in the window, press Temperature*▲* or *▼* buttons until the desired code flickers in the window. When the code is right, the air conditioner will start.



3. Press OK button and the selected conditioner type code will stop flickering.




4. Test whether the remote control button has been effectively set. If yes, setting completes. And if no, repeat steps 2-3.



C Digital automatic search type


1. Manually plug-in the air conditioner, aim the remote control at the receiving window of the air conditioner.



2. Hold SET button (for about six seconds) until the conditioner type code changes in the window, indicating you have entered the high-speed conditioner type search status. press OK button to stop searching until the air conditioner automatically starts.



3. Test whether the functions of remote control buttons (excluding Temperature and buttons, timed ON/OFF buttons, and SET button) are correct. If yes, the code is effectively set. If not, press SET button to continue once the search.



Set Time Function

Press CLOCK button (for three seconds) to enter the clock setting status, and the clock will flicker. Use the Temperature*▲* or *▼* buttons to adjust the current time, and press CLOCK button again to exit setting.



Timing ON/OFF Function

To configure the timer function of the original remote control, press TIME ON or TIME OFF buttons, and the air conditioner timer lights will go on, indicating the air conditioner has entered the timed status.

*The timed ON function of some of the air conditioner types is only valid only in the Power Off status.

Warm Tips:



- This remote control is effective if the air conditioner receiver works normally.
- If this remote control is intended to be not in use for a long time, please remove the batteries.
- It may possibly caused internal program disorder if this remote control is not operated correctly, in case of that, please take out the battery, and install the batteries 35 minutes later, then the remote control may recover normal.

Applicable brand and code list

Brand	Code	Brand	Code	Brand	Code	Brand	Code
ACSOM	980	FEDDERS	878	KTY003	287	SHINING	415
ADC	861	FEIEDRICH	879	KTY004	288	SHUANGLU	416~418, 948
AIDELONG	293~295	FEIGE	829~830	KTY005	289	SIGMA	447
AITE	296~299	FEILU	240~249	LG	600~609	SOGO	291
AKIRA	796~797	FERROLIT	901	LIANGYU	780	SONGLINXIA	862
AMCOR	501, 508, 509, 532, 973, 978, 979	FIRST	864	LIKEAIR	386~387	SONGXING	419
AMICO	982	FRESTECH	270~279, 944~945	LITTLESWAN	453	SOVA	292, 420
ALPIN	986~991, 998	FUJITSU	700~719	LONGHE	861	SOWA	862~863
AUCMA	210~229, 903	Funiki	992	LOREN-SEBO	801~803	SOYEA	421~422
AUX	186~199	GALANZ	134~149, 936~940	MOQUAY	790~795	SPEED	987
AOKE	301~302	GEER	342~343	MIDEA	040~058	SRTC	423
AOLI	304	GLEE	280	MEILING	388~391	STARIGHT-AIRCON	880
APTON	862	GOLDSTAR	303	MINGXING, BOYIN	290	SUNBURG	817~820
BAIXUE	299	GREE	000, 020~039	MITSUBISHI	551~599	TADAIR	501, 508, 509, 532
BEIJINGJINGDIAN	304	GUANGDA	345~346	MITSUKA	904	TADIRAN	501, 508, 509, 532, 630, 948, 978, 979, 991
BIG-THUMB	331	GUQIAO	344	NATIONAL/Panasonic	660~689	TAIYA	862
BLUE STAR	887	HAIER	001~019	NIKKO	810~811	TCL	120~133
BOERKA	305, 306, 630	HELTON	863	NISO	398~399, 497	TEAC	850~859
BOSHI	310	HEMILTON	095	NORCA	994	TECO	831~834
BOSHIGAO	308~309	HICON	391~392	OLYMPUS	995~996	TIANJINKONGTIAO	424
BORLER	307	HISENSE	230~239	OPAL	997	TIANYUAN	425~428
CAIXING	311	HITACHI	640~659	PANDA	464~466	TOBO	250~269
CARRIER	680~699, 890~899	HONGYI	347	PEREG	998	TONGLI	429~430
CHANGFENG	190	HUABAO	100~109	PINSHANG, XINHUABAO	290	TOYO	825~828
CHANGFU	835~838	HUAGAO	348	PILOT	902	TOSHIBA	630~639
CHANGLING	312~323	HUAKE	349~350	PUYI	862	TRANE	812~816
CHANGHONG	059~079, 934, 947	HUAMEI	351~352	QIXING	393	UNI-AIR	368~369
CHENGYUAN	324	HUANGHE	353	RAYBO	371~383	UTTLEDUCK	454~456
CHIGO	080~089	HUALING	150~169, 045	RHOSS	903	VIDEOCON	884
CHUANGHUA	325~328	HUAWEI	281	RICAI	394	WANBAO	431~433
CHUANYAN	861	HUIFENG	354~356, 357, 360	RIJIANG	395~397	WANGZI	861
COLROLLA	861	HYUNDAI	780~789	ROWA	383~385	WEILI	434~443, 553~576
CHUNLAN	170~179	INYCIN	475~483	SACON	414	WEITELI	444
CONSUL	993	JIANGNAN	359	SAMSUNG	610~629	WHIRLPOOL	770~774
CONROWA	337~341	JIALE	358	SANYO NEC	500~550, 860, 943, 946	WUFENG	445~446
CORONA	760~769	JMSTAR	360	SANZUAN	190	XINGHE	462~463
CROWN	861	JINBEIJING	361~362	SAPORO	861	XINLE	457~460
DAEWOO	332~333	JINDA	491~492	SAST	450~452	XILENG	448~449
DAIKIN	740~759	JINSONG	363~365	SENSOR	860	XINLING	461
DAJINXING	329~330	JOHNSO	282	SERENE	499	XIONGDI	862
DAKE	861	KANGLI	368~370	SHAMEI	400	YAIR	467~471, 044
DAOTIAN	821~824	KELONG	110~119	SHANGLING	403~409	YAOMA	470, 977
DELONGHI	900	KLIMATAIR	797~800	SHANYE	862	YIDONG	499
DIY	044, 090, 092, 095	KONKA	366~367	SHANKING	401~402	YORK	775~779
DUNAN	336	KRIS	804~805	SHARP	720~739	YUTU	484~490
DONGXIA	334~335	KT02_D001	283	SHENBAO	410~411	ZHONGYI	493~494
DONGXINBAO	260~268	KT02_D002	284	SHENGFENG	412	ZUODAN	495
ELCO	982	KTY001	285	SHENGFENG/FEILU	413	YUETU	881~882, 949
ELECTER	981~986	KTY002	286	SHINCO	200~209	OTHER	496, 498, 821~828, 839~849, 865~877, 905~976, 999
ELECTROLUX	471~474, 250, 906						